



Caring Beyond Our Products

Elaso Balancing Systems List

System	Part	Part#	Comment
eb500-230	Controller 115/230V	14852	table top housing
eb500-024-e	Controller 24Vdc	14842	operator panel mounted
ebg1500-1w	Controller 24Vdc	18655	balancing only, no gap, 1 filter
ebg1500-2w	Controller 24Vdc	18656	balancing only, no gap, 2 filter
ebg1500-1g1i	Controller 24Vdc	18841	1 1-input gap
ebg1500-2g1i	Controller 24Vdc	18658	2 1-input gap
ebg1500-1g2i	Controller 24Vdc	18842	1 2-input gap
ebg1500-2g2i	Controller 24Vdc	18850	2 2-input gap
ebg1500-1g1i-1f	Controller 24Vdc	18843	1 1-input gap, 1 filter
ebg1500-2g1i-1f	Controller 24Vdc	18661	2 1-input gap, 1 filter
ebg1500-1g1i-2f	Controller 24Vdc	18660	1 1-input gap, 2 filter
ebg1500-1g2i-1f	Controller 24Vdc	18657	1 2-input gap, 1 filter
ebg1500-1g2i-2f	Controller 24Vdc	18659	1 2-input gap, 2 filter
eb2000-a	Controller 115/230V	15114	automatic balancing
eb2000-m	Controller 115/230V	15115	manual balancing
eb4500	Controller 115/230V	18248	table top housing
eb4500	Controller 115/230V	15970	no housing, integrated op interface
eb4500-e	Controller	18696	external control
eb4500-eu	Controller	18696	external control, angle bracket
eb4500-b	Operator interface	15358	display not background lit
eb4500-c	Operator interface	19049	display background lit
eb6001-d	Controller 24Vdc	16603	replacement for eb7000 line
eb6001-d	Controller 24Vdc	18938	for remote control
eb6001-pui	Operator interface	18942	remote interface, panel mounted
ems1000	Controller module system	18199	older version
ems1000	Controller module system	17769	new version V2
usc5000	Structure-borne sound module	17764	old version
usc5010	Structure-borne sound module	18839	new version
usc5020-od	Structure-borne sound module	18925	no lid
vmf1000	Filter module	17760	balancing filter
usc2000	Structure-borne sound controller	16664	panel mounted, LCD display
usc4000	Structure-borne sound controller	18305	panel/surface mounted, LED indicator
usc4000	Structure-borne sound controller	18222	rack mounted
ebu002	Change-over box	16347	switching between 2 balancing heads
Transducer	Part	Part#	Comment
vas002-015	Vibration transducer	15376	0.15m cable length, magnetic base or base plates, for eb2000, eb4500, eb7000
vas002-01	Vibration transducer	14443	1m cable length, magnetic base or base plates, for eb2000, eb4500, eb7000
vas002-04	Vibration transducer	15310	4m cable length, magnetic base or base plates, for eb2000, eb4500, eb7000
vas002-06	Vibration transducer	15377	6m cable length, magnetic base or base plates, for eb2000, eb4500, eb7000
vas002-08	Vibration transducer	15311	8m cable length, magnetic base or base plates, for eb2000, eb4500, eb7000
vas002-10	Vibration transducer	15378	10m cable length, magnetic base or base plates, for eb2000, eb4500, eb7000
vas002-13	Vibration transducer	15312	13m cable length, magnetic base or base plates, for eb2000, eb4500, eb7000
vas002-20	Vibration transducer	16573	20m cable length, magnetic base or base plates, for eb2000, eb4500, eb7000
vas005-01	Vibration transducer	16159	1m cable length, magnetic base or base plates, for eb500, ems1000, ebg1500
vas005-04	Vibration transducer	16160	4m cable length, magnetic base or base plates, for eb500, ems1000, ebg1500
vas005-06	Vibration transducer	16161	6m cable length, magnetic base or base plates, for eb500, ems1000, ebg1500
vas005-08	Vibration transducer	16162	8m cable length, magnetic base or base plates, for eb500, ems1000, ebg1500
vas005-10	Vibration transducer	16163	10m cable length, magnetic base or base plates, for eb500, ems1000, ebg1500
vas005-13	Vibration transducer	16164	13m cable length, magnetic base or base plates, for eb500, ems1000, ebg1500
Sound sensor	Part	Part#	Comment
uss001-03	Structure-borne sound sensor	15407	3m cable length, no connector, square, mounting hole
uss001-04s	Structure-borne sound sensor	13880	4m cable length, 3-pin connector, square, mounting hole
uss001-04s5	Structure-borne sound sensor	18410	4m cable length, 4-pin connector, square, mounting hole
uss001-10s	Structure-borne sound sensor	18613	10m cable length, 3-pin connector, square, mounting hole
uss001-10s5	Structure-borne sound sensor	18699	10m cable length, 4-pin connector, square, mounting hole
uss002-e-0015	Structure-borne sound sensor	17662	0.15m cable length, no-contact receiver
uss002-e-02	Structure-borne sound sensor	18184	2m cable length, no-contact receiver
uss002-e-04	Structure-borne sound sensor	17676	4m cable length, no-contact receiver
uss002-e-10	Structure-borne sound sensor	17679	10m cable length, no-contact receiver
uss002-s	Structure-borne sound sensor	17661	gap microphone, no-contact transmitter

CIRO Products Ltd
PO Box 1432
Hickory 28603-1432 USA

Toll free: (888) ASK CIRO
Phone: (828) 345-6030
Fax: (828) 345-6013

Web: www.ciro.com
E-mail: info@ciro.com



Caring Beyond Our Products

System	Part	Part#	Comment
uss003	Structure-borne sound sensor	18226	gap microphone, no-contact transmitter
Collector	Part	Part#	Comment
sta062-ca-ej1	Collector	14943	with flange, no sound monitoring, lateral connector
sta062-da-ej1	Collector	14942	with flange, no sound monitoring, axial connector
sta062-ca-ej2	Collector	14941	with flange, no sound monitoring, lateral connector
sta062-da-ej2	Collector	18164	with flange, no sound monitoring, axial connector
sta062-ca-rw1	Collector	14948	with flange, no sound monitoring, lateral connector
sta062-ca-kb1	Collector	14949	with flange, no sound monitoring, lateral connector
sta062-da-kb1	Collector	16998	with flange, no sound monitoring, axial connector
sta062-da-ez1	Collector	14940	with flange, no sound monitoring, axial connector
sta062-ca-ez3	Collector	14944	with flange, no sound monitoring, lateral connector
sta062-da-ez3	Collector	16997	with flange, no sound monitoring, axial connector
sta062-da-ez4	Collector	14950	with flange, no sound monitoring, axial connector
sta090-gc-ej1	Collector	18754	no-contact, with sound monitoring, lateral connector
sta090-gc-rw1	Collector	18755	no-contact, with sound monitoring, lateral connector
sta090-ia-uw1	Collector	18083	no-contact, no sound monitoring, lateral connector

All text, technical data, measurements and samples were prepared thoroughly. However Elaso and CIRO Products Ltd. cannot be held liable for errors and omissions. Elaso and CIRO Products Ltd. reserve the right to improve or change the design of hard and software and make changes to the technical documentation without further notice.

CIRO Products Ltd
 PO Box 1432
 Hickory 28603-1432 USA

Toll free: (888) ASK CIRO
 Phone: (828) 345-6030
 Fax: (828) 345-6013

Web: www.ciro.com
 E-mail: info@ciro.com