

Elaso/Kellenberger Balancing Parts X-reference (sorted by Kellenberger #)

Item description	Type	Elaso item #	Kellenberger item #	Old Kel #
External balancing head manual	ebb108-1000-aa	12859	110840	
External balancing head wire-bound, internal mounted	ebb115-1600-ca	14903	115492	
External balancing head manual	ebb108-0750-aa	12860	117172	
External balancing head, wire-bound, internal mounted	ebb115-0900-ca	14901	117173	
Vibration transducer	vas002-08	15311	120592	132618
Vibration transducer	vas002-06	15377	120812	
Front plate module Kellenberger	EB-5TAST	15455	130828	
Controller without display for brush type collector	EB-5003S	15454	135563	
Connecting cable no-contact, 7 leads, eb7000, eb6001	vbk007-b-08	14987	138600	
Connecting cable no-contact	VB15-10-06/07	19065	138600	
Connecting cable new front plate to eb7000, eb6001	VB09-08-09/08	19005	138601	
Operator interface Kellenberger	EB-7F/kel	15338	138603	
Controller module automatic GAP + blind plate	EB-7003/BP	16603	138604	148355
Controller external w/GAP	eb6001-d	18938	138604	
Transmitter lateral	STB37SS	14220	138612	
Balancing head complete ebf115	EBF115	19112	138613	
Extension cable	vlk002-a-06	15044	142226	
Processor module	eb500-024-e	14842	145833	
Vibration transducer with 18036 plate	vas005-04	16160	145834	
Protractor ring 360ø Kellenberger	S080/140	16008	145835	
Protractor ring 360ø Kellenberger	S095/123	16009	145836	
Balancing head complete ebf115+stb37ss	EBF115	19114	146390	
Connecting cable no-contact	vbk007-b-10	14988	146552	
Extension cable for vas002	vlk002-a-08	15314	146553	
Vibration transducer	vas002-04	15310	146590	117420
Vibration transducer	vas002-01	14443	146799	
External balancing head+transmitter+adapter+GAP	ebb130-1270-jc	16686	146827	
Controller manual	eb2000-m	15115	147539	
Switch box for 2 balancing heads	ebu002	16347	148356	
Connecting cable no-contact	vbk007-c-014	19113	148357	
Extension cable for vas005	vlk005-a-13	17356	149771	
External balancing head BL complete 36V	ebb130-1270-jc	17191	149832	
Processor module 24VDC panel mount	EB500M2/24	17379	151528	
Filter for balancing processor	EB500/ZM	17361	151529	
VA5 replacement	VA5A	17614	152205	
Structure-borne sound sensor no-contact	uss002-e-04	17676	152614	
ems1000 including power cable	ems1000	17769	153473	
Structure-borne sound sensor no-contact	uss002-s	17661	154197	
GAP module	usc5000	17764	154198	
Filter module	vfm1000	17760	154199	
Structure-borne sound sensor receiver	uss002-e-02	18184	154249	
Cable for GAP 5m	vlk005-b-05	17419	154279	
Operator interface for eb7000x	EB-7F/ext	14001	154770	
Cable for GAP 7m	vlk005-b-07	18873	155416	
Extension cable for vas005	vlk005-a-07	18805	155417	
External balancing head complete (Kel-Vera)	ebz050-160-1500-k	19105	155678	
Helix cable 4 leads	spk004-a-060	15015	155679	
Helix cable 8 leads	spk008-a-060	15023	155679	
Flange for stb110 [KEL-VERA]	Flange KEL-VERA	19102	155681	
Receiver noGap with 8pin plug V3	sta110-0a	19118	155682	
Transmitter w/Gap coil and driver V2	sta110-s	18911	155683	
Vibration transducer with 18036 plate	vas005-01	16159	156218	
Extension cable for vas005	vlk005-a-05	18311	156219	
Connecting cable no-contact	vbk007-a-10	15031	156654	
External bal head complete w/ring + driver	ebb130-1270-nc	18426	158596	
User interface for eb6001-c /-d	eb6001-pui	18942	160080	
Adapter ring complete internal grinding Kel		18893	160285	
ebg1500 1 2-input GAP	ebg1500-1g2i	18842	160346	
External bal head no-contact driver M33x1.5 left	ebb130-1270-oc	18986	160384	
External bal head no-contact driver M33x1.5 right	ebb130-1270-oc	18987	160396	
ems1100 including ProfiBus -DPSlave	ems1100-Profibus	18765	160963	
1 input GAP module	usc5010	18839	161090	

GAP receiver, mount and seal		18844	KEL161283
ebg1500, 1, 2-input GAP 1 filter	ebg1500-1g2i-1f	18657	KEL161509
ebg1500, 1, 2-input GAP 2 filter	ebg1500-1g2i-2f	18659	KEL161510
Cable for GAP through mounting	vlk005-c-10	18812	KEL161511
Cable for GAP 3m	vlk005-b-03	18863	KEL161534
Cable for GAP 10m	vlk005-b-10	18185	KEL161535
Extension cable for vas005 3m	vlk005-a-03	18864	KEL161536
Extension cable for vas005 10m	vlk005-a-10	17377	KEL161537
Positioning ring stp110		19315	KEL600137
Threaded adapter for ebb130		14815	n/a
Threaded adapter for ebf130		15611	n/a
Square plate for va	PqV	18036	n/a
2 input GAP module	usc5020	18840	n/a
1 input GAP module no cover	usc5010-od	18924	n/a
2 input GAP module no cover	usc5020-od	18925	n/a
Threaded adapter for ebf130		18988	n/a
Threaded adapter for ebf130		18990	n/a
Threaded adapter for ebb130		19007	n/a
Threaded adapter for ebb130		19017	n/a